

**tc electronic®**

**CORONA**  
CHORUS



*USER'S MANUAL*

# Important Safety Instructions

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not install near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Only use attachments/accessories specified by the manufacturer.
- 10 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped

## Warning!

To reduce the risk of fire or electrical shock, do not expose this equipment to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the equipment.

Do not install in a confined space.

## Service

All service must be performed by qualified personnel.

## Caution:

You are cautioned that any change or modifications not expressly approved in this manual could void your authority to operate this equipment. When replacing the battery follow the instructions on battery handling in this manual carefully.

## EMC/EMI

This equipment has been tested and found to comply with the limits for a Class B Digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses and can radiate radio frequency energy and – if not installed and used in accordance with the instructions – may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception – which can be determined by turning the equipment off and on –, the user is encouraged to try correcting the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For the customers in Canada:

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

# Introduction

Congratulations! You have just bought a chorus pedal that is a stepping stone to a world of inspiration, innovation and tone.

We are proud to present Corona Chorus, providing TC Electronic's legendary chorus sounds, intuitive controls, and instant satisfaction. From a chorus sound that meets session player standard over classic80's clean chorus to contemporary choruses, it's there in all of its chorussy glory. We love tone as much as any guitarist out there, and we always aim at pushing the boundaries. We are therefore very excited to present a brand new, groundbreaking concept: TonePrint!

TonePrint gives you instant access to custom-tweaked sounds. We have gathered an impressive list of guitar heroes and had them tailor their signature sounds – the tones that made them famous. TonePrint will not just bring you close to the sounds of your idols, they give you their actual sounds!

Using TonePrints is both easy and fun. Just download the TonePrint you want from [www.tcelectronic.com](http://www.tcelectronic.com) et voilà, your favorite artist has just put a TonePrint in your pedal. Forget emulation – let's talk collaboration!





## Connecting

**Input jacks** - Use MONO for mono input and both MONO and STEREO if connecting a stereo source. If you run the pedal on battery, we recommend removing the mono input jack to preserve battery power when you don't play.

**Output jacks** – Connect to another pedal or directly into an amp or mixer. Use MONO for mono setups and both MONO and STEREO for stereo setups. Notice that it is possible to select between true bypass and buffered bypass mode via a dip switch located under the battery cover.

**Power in** – Use a 9 VDC power supply with center negative, 5.5 mm / 2.1 mm connector.

### USB

Connect to a computer using the supplied USB cable for upload of TonePrint patches. The connector-type is Mini-B.

## The Controls

### FX LEVEL

Controls the intensity of the chorus. The chorusing effect occurs when a pitch modulated signal – think vibrato – is played adjacent to a clean signal. Therefore the max chorus intensity is achieved at a 50%wet/dry mix. With Corona, this is achieved by setting the FX level fully clock-wise.

### SPEED

The SPEED knob sets the chorus speed – from slow smooth "Hi-Fi" to much more significant "Leslie"types at high speed.

### DEPTH

DEPTH sets the range of the modulation. Experiment with both the SPEED and DEPTH controls to get the effect you are looking for.

## TONE

By adjusting the tone you can set how warm your chorus should sound. When using high settings on both speed and depth for that "leslie-type" sound you might want to emphasize the lower frequencies over the higher ones. Try turning TONE counter clock wise.

## CHORUS TYPE selector

The Chorus Type selector allows you to select between the following types:

### CHORUS

Standard chorus inspired by the legendary TC Stereo Chorus Flanger.

### TRI (Tri-Chorus)

The Tri-Chorus is a variation of the regular Chorus that uses three stereo Choruses with various offsets for both depth, speed, phase, and chorus delay time to produce a unique, very broad and lush Chorus sound.

## TonePrint

Consider the knobs and switches on your pedal as a few handles that actually control a large number of parameters. TC Electronic staff has defined the controls, - but wouldn't it just be cool to let the world's leading guitar players contribute with their own definition of how the controls should work? YES - this is TonePrint. We allow top guitar players to dig out the pedals' hidden tonal potential, re-define the controls and make their own TonePrints. These TonePrints are available for you, and uploading TonePrints to your pedal is easy.


- Connect the pedal to your Mac or PC computer using the supplied USB cable.
- Find your pedal at [www.tcelectronic.com/pedals](http://www.tcelectronic.com/pedals) and download the TonePrint setting from your favorite guitar player to a location where you can easily locate it again – e.g. your desktop.
- Open the application and press UPDATE. Now – once you have selected TonePrint, all controls react exactly as defined by the artist that has provided the TonePrint.

## Bypass modes and Kill Dry on/off


Unscrew the back-plate and look for the two small dip-switches in the upper left corner.

The upper dip-switch (closest to the DC 9V in connection), switches between True Bypass mode(default) and Buffered Bypass mode.


True Bypass




Buffered Bypass



Kill-Dry - off



Kill-Dry - on



True Bypass – is a hardwire bypass that gives absolutely no coloration of tone when the pedal is bypassed. Using True Bypass on all pedals is a perfect choice in setups with a few pedals and relatively short cables before and after the pedals.

Buffered Bypass – If you use a long cable between your guitar and the first pedal, if you use many pedals on your board and if you use a long cable from your board to the amp, then the best solution will most likely be to activate the buffer in the first and last pedal in the signal chain. Can you hear the difference between a pedal in True Bypass or Buffered Bypass? Maybe, maybe not, – many factors apply; active/passive pick-ups, single coil/humbucker, cable quality, amp impedance and more. We cannot give a single ultimate answer. Use your ears and find the best solution for your setup!

Kill-Dry on/off – With Buffered Bypass activated (upper switch to the right), the lower dip-switch sets Kill-Dry on/off. Kill-Dry removes all direct signal from the pedals output and is the mode to use when the pedal is placed in a parallel effects loop. Kill-Dry is NOT an option in True Bypass mode.

Changing battery – Unscrew the thumb-screw on the back of the pedal and detach the backplate. Unmount the old battery and attach the new battery to the battery clip making sure the polarity is correct. Then remount the back-plate. To save battery life, remove the input jack when you don't play. Batteries must never be heated, taken apart or thrown into fire or water. Only rechargeable batteries can be recharged. Remove the battery when the pedal is not being used for a longer period of time. Dispose batteries according to local laws and regulations.

## Technical Specifications

Sounds	2 amazing chorus effects: A 1:1 recreation of the legendary TC Electronic Chorus/Flanger pedal and the new TriChorus that packs three TC choruses into one unbelievably lush effect Unique, new TonePrint setting for stuffing Corona Chorus with your favorite artist's tones
Size & Weight	72 mm x 122 mm x 50 mm - 300 g (excl. battery)
Battery	Dual Supply Rails technology ensures headroom for line level effect loops from a single 9Vbattery. Battery failure circuit automatically puts Corona Chorus into true bypass mode if the battery runs out
Design	Custom 'hammerhead' rugged, die-cast aluminum casing built for a life on the road Unique one-screw battery access for lightning fast battery changes
Connectors & Inputs/Outputs	Stereo inputs with automatic mono/stereo sensing – feed it any signal Stereo outputs for that ultra-wide chorus sound Mini USB connector for uploading custom TonePrints and software updates
Knobs etc.	Speed, Depth, FX Level and Tone knobs with high-quality, metal-shaft potentiometers Heavy duty tactile footswitch with true bypass for zero tone coloration
In the box	USB cable for uploading TonePrints, Owner's Manual, TC Electronic Guitar Pamphlet, TC Electronic Sticker.

These specifications are subject to change without notice.

**tc electronic®**

*TC Electronic, Sindalsvej 34, DK-8240 Risskov*

*info@tcelectronic.com*